


図 1



0994943-1221

図 2



図 3





FIG. 2

图 4



108211" E4646660

図 5



09094943 112301
T0821T E4646660

図 6

(A)




Figure 6A is a screenshot of a mobile device screen. At the top left, there is a signal strength indicator (three bars) and a battery level indicator (four bars). The text "名前を登録してください" (Please register your name) is centered on the screen. Below this text is a text input field containing the name "やまだたろ" (Yamada Tarō) followed by a black square cursor.

(B)




Figure 6B is a screenshot of a mobile device screen, similar to Figure 6A. It shows the same signal and battery indicators at the top. The text "名前を登録してください" (Please register your name) is centered. Below this text is a text input field containing the name "やまだたろう" (Yamada Tarō).

06994943.112301

図 7





FIG. 7

図8



0994943.112001
 708217.4464660

図 9






図 1 1



0904943-11201

図 1 2



00000000h

図 1 3



FIG. 13

図14

| d07 | d06 | d05 | d04 | d03 | d02 | d01 | d00 |
|-----|-----|-------|-------|-------|-------|-------|-------|
| - | - | LCNT5 | LCNT4 | LCNT3 | LCNT2 | LCNT1 | LCNT0 |

LCNT0: モード選択フラグ

0: 電話

1: ゲーム

LCNT1: 2値画像出力制御フラグ

0: 中止

1: 出力

LCNT2: カラー画像フレンディング制御フラグ

0: ノーマル

1: フレンディング

LCNT4,3: カラー画像トーン制御フラグ

00: 中止

01: トーンダウン

10: 等倍トーン

11: トーンアップ

LCNT5: LCD表示オンオフフラグ

0: 表示オフ

1: 表示オン

LCNT0: E4646660

図15

ゲームキーレジスタ1

| d7 | d6 | d5 | d4 | d3 | d2 | d1 | d0 |
|----|----|----|----|----|----|----|----|
| K7 | K6 | K5 | K4 | K3 | K2 | K1 | K0 |

K7:SELECTキー

K6:STARTキー

K5:十字キー(右)

K4:十字キー(左)

K3:十字キー(下)

K2:十字キー(上)

K1:Bボタン

K0:Aボタン

ゲームキーレジスタ2

| d7 | d6 | d5 | d4 | d3 | d2 | d1 | d0 |
|-----|-----|-----|-----|-----|-----|-----|-----|
| KI7 | KI6 | KI5 | KI4 | KI3 | KI2 | KI1 | KI0 |

KI7:SELECTキー

KI6:STARTキー

KI5:十字キー(右)

KI4:十字キー(左)

KI3:十字キー(下)

KI2:十字キー(上)

KI1:Bボタン

KI0:Aボタン

ゲームキーレジスタ3

| d7 | d6 | d5 | d4 | d3 | d2 | d1 | d0 |
|-----|-----|-----|-----|-----|-----|-----|-----|
| KO7 | KO6 | KO5 | KO4 | KO3 | KO2 | KO1 | KO0 |

KO7:SELECTキー

KO6:STARTキー

KO5:十字キー(右)

KO4:十字キー(左)

KO3:十字キー(下)

KO2:十字キー(上)

KO1:Bボタン

KO0:Aボタン

FIG. 15

図 1 6





図 1 7



Sheet 15 of 39

FIG 18



FIG 19




FIG 19

図 20





図 21



09094943-112301

図 2 2




FIG. 22

図 2 3






FIG. 23

図 2 4




09904943-11201
T082T E464660

図 25




0994943 12301
T0321 E4646660

図 26




00004943.12301
TEST.E4646660

図 27




0994943-112801

図 28




103277-CH646660

図 29



0994943.112301
103211 E4646660

図 3 0



0904943-112301 E4646660

図 3 1




FIG. 31

図 3 2


0000000000101001 : キー割当依頼
0000000000001010 : 「#」を示すキーコード
0000000010000000 : セレクトを示す機能情報
0000000000001011 : 「*」を示すキーコード
0000000001000000 : スタートを示す機能情報
0000000000000000 : エンドコード

図 3 3

34a

| キー | キーコード | 機能情報 |
|----|-------|------|
| # | 1010 | セレクト |
| * | 1011 | スタート |
| 0 | | |
| 1 | | |
| 2 | | |
| : | : | : |
| 9 | | |

図 3 4



Sheet 1 of 1

図 3 5






FIG. 35

図 3 6

(A)



(B)



(C)



103211 6454560

図 37

(A)

やまだたろ ■

Figure 37(A) shows a mobile phone screen with a signal strength indicator (four bars) in the top left corner and a battery level indicator (four bars) in the top right corner. The name "やまだたろ" (Yamada Taro) is displayed in the center of the screen, followed by a small black square icon.

(B)

名前を登録してください


(C)

やまだたろ ■


Figure 37(C) shows a mobile phone screen with a signal strength indicator (four bars) in the top left corner and a battery level indicator (four bars) in the top right corner. The name "やまだたろ" (Yamada Taro) is displayed in the center of the screen, followed by a small black square icon.

図 3 8

(A)



(B)



(C)





FIG. 38

図 39



FOOT-CH4660

図 40





FIG. 40

図 4 1




TEST CH6666

ゲームCPU表示処理



図 4 3



Sheet 38 of 39

図 4 4




図 4 5

